



VD1-VD3, S1 MUST BE MOUNTED
TO BACK (SOLDER) SIDE.