



XS2		
У	Цепь	Адрес
1	Вых. DC	=A10-XP1:1
3	Вых. лев.	=A10-XP1:3
4	Вых. лев.	=A10-XP1:4
5	Вых. лев.	=A10-XP1:5

XP1

←	Цель	Адрес
1	-288	=A9-XS4:1
2	-288	=A9-XS4:2
4,5	+288	=A9-XS4:5 ⁴
6,7	+288	=A9-XS4:7 ⁵

XS4

←	Цель	Адрес
1	+33В	=A9-XS2:1
2	-33В	=A9-XS2:2
4	Общий	=A9-XS2:4
5	Вых. лев.	=A9-XS2:5
6	Вых. лев.	=A9-XS2:6
7	Общий	=A9-XS2:7

XP3

←	Цепь	Адрес
3	8VT23	AB-XS2:3
4	8VT23	AB-XS2:4
1	8VT23	AB-XS2:1